


Solvent Pass-Through Check Valve for Customer Field Installation, Stainless Steel - 25968

Product Images



Short Description

- Includes safety check valve to prevent backflow
- Use to dispense liquid into or dispense liquid out of the cabinet
- All stainless-steel construction
- Customer-installed in the field

Description

The Pass-through Check Valve (model 25968) can be used on the sides or back of flammable liquid safety cabinets. This unique system provides a means to dispense solvent through the wall of a cabinet. It can be installed either to dispense liquid into or dispense liquid out of the cabinet. Two ¼-in NPT threaded fittings (not included) are required to thread into both sides of the pass-through. Only install on the sides and back of the safety cabinet, never on the doors, bottom or top of a cabinet.

Note: This item is for the customer's field installation only and will void the safety cabinet's FM Approval. Please see the [instruction guide](#) for more information. This [TechTALK](#) has guidelines for ordering factory-installed pass-through, check valves for Justrite safety cabinets to maintain FM Approval and our 10-year warranty.

Specifications

Model No	25968
UPC	697841008618
International Model No.	25968
Net Weight, lbs	0.7
Net Weight, kg	0.3